



Comfort Chair - Heat and Massage Options



= Heating Element*



= Massage Motor



[HV-3](#)



[HV-4](#)



[HV-5 Option 1](#)



[HV-5 Option 2](#)



[HV-6 Option 1](#)



[HV-6 Option 2](#)



[HV-6 Option 3](#)